

FiLIP.

# FiLIP 2 QUICK START GUIDE



Connected  
by AT&T



## Step 1



Turn your FiLIP on by pressing the red button firmly for 1 second.

## Step 2



- 1 - Download the FiLIP mobile app from the App Store or Google Play to your iOS or Android device.
- 2 - When prompted, choose AT&T as the network provider for your FiLIP.

## Step 3



Make sure you have the phone # for your FiLIP in front of you.  
It should be located on your receipt.

## Step 4



Launch the FiLIP mobile app, create a FiLIP account and then follow the prompts to sync your FiLIP with the app. Your FiLIP must be on and next to you during this process so that it can receive the 6-digit activation code.

## Step 5



Put the FiLIP on your child's wrist, kick back and let them have some fun.

# GET TO KNOW YOUR FiLIP!



Your FiLIP has 2 simple buttons and a charging port.



## What does the big red button do?

Press it firmly for 1 second to turn on your FiLIP.

Press it to make a call once you've selected a contact.

Press it to hang up when you are done with a call.

Press and hold it for 4 seconds to initiate Emergency Mode.

Press it to switch between displays.

## What does the black button do?

Press it to scroll through your contacts.

Press it to scroll through texts.


## What do the buttons do together?

Your FiLIP can be turned off through the FiLIP app or by pressing both buttons at the same time. To turn off your FiLIP using the buttons, press the red and black buttons at the same time and hold for approximately 30 seconds. When prompted, press "Shutdown" and follow the prompts. Do NOT press "Factory Reset."



## Your FiLIP can be worn open or closed

Your FiLIP wristband comes with an “End Cap” for your child to wear it open, a “Latch” for your child to wear it closed, and an “Extender” to adjust the size.



## The size of your FiLIP can be adjusted

To wear the FiLIP closed, determine the size of your child's wrist. If your child's wrist is 4.8" or less, they will only need the "Latch Spacer." If your child's wrist is larger, then they will need either the "Latch" + "Medium Extender" (up to 5.2" wrist) OR the "Latch" + "Large Extender" (up to 5.6" wrist).

The end cap, latch and extenders are designed to slide on and off of the FiLIP wristband, as shown. Do NOT try to push or snap them on and off, as that may cause them to break.

# NEED TO KNOW MORE?

## Technical Support



Visit [myfilip.com/support](https://myfilip.com/support) for helpful information on how to use your FiLIP and FiLIP app.

## Follow Us!



<https://www.facebook.com/myfilip>



<https://twitter.com/myFilipTech>



<http://www.pinterest.com/myfilip/>



<http://instagram.com/myfilip>

© 2015 Filip Technologies, Inc. All Rights Reserved. AT&T and the AT&T logo are trademarks of AT&T Intellectual Property.

\*FiLIP watch only capable of connecting to the AT&T network. See [att.com/network](http://att.com/network) for coverage details.

TERMS OF SERVICE: A copy of Filip Technologies, Inc. full terms of service are available online at [myfilip.com/legal](https://myfilip.com/legal).

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries.

App Store is a service mark of Apple Inc. Google Play is a trademark of Google Inc.

